

# Installation Guide

## Solenoid Valve

### Types EVRP 0.85 and EVRP 3


032R9228

032R9228


#### Refrigerants:

R404A


Oil: General used ISO 32 POEs





#### Mounting directions




#### Soldering



#### Dismounting and mounting



#### Correct sealing



To ensure correct sealing between coil and valve mount the coil in the proper position and make sure that the coil is fully clicked on to the valve.

